

UB Components Sump Guard

First fit the rear bolts, washers and spacers and leave them loose and hanging down, then slide the rear of the guard on top of the washers.

Lift the front of the guard in to place (use a trolley jack to support the guard) and fit the middle and front bolts and spacers.

Make sure all the bolts are wound in a few turns before tightening.

