UB HD Gas Strut Kit

Tools needed: Hand drill, Rivet gun, 26mm spanner, Prop, Small fact screw driver and 5mm Allen key.



T6 Gas Strut Kit (for T5 the top bolt on lower plate is swapped for a rivet).

1. Prop up tailgate.

2. Remove OEM gas struts and ball extensions.

3. Offer up the top brackets and hold in place with the M8 button head bolt and spring washer.

4. Mark the holes for the rivets.

5. Remove the brackets and drill holes for rivets with 6.5mm drill.

CAUTION: use a depth collar to prevent damage to outer door skin and wiring loom (LHD side).

6. Treat bare metal with rust proof paint.

7. Fit brackets with M8 bolts and rivets.

8. Fit the lower strengthening plate and lower stud using the bottom hole.

T5 - Mark and drill the top hole for 6.5mm rivet.

T6 - Fit M8 bolt and spring washer to top hole.

9. Fit the gas struts with the main strut body and the top.

10. Fit spring clips



